

Total Station Transmission Software

**Total Station Transmission Software
Manual**

Catalogue

1. Software Introduction	3
1.1 Software Introduction	3
2. Installation of Data Cable Driver	3
2.1 Installation Steps of Data Cable Driver	3
3. Software Usage	7
3.1 Transmit Data from TS to PC	7
3.2 Transmit Data from PC to Total Station.....	17
3.3 Copy Data and Paste Data.....	22
3.4 Create Coordinate File	24
4 Instruction of connecting controller with the instrument by Bluetooth	28
4.1 Set in total station.....	28
4.2 Set in the controller	28
1. Bluetooth Settings	28
2 Bluetooth connections in SurvCE	31
3 Store points	32

1. Software Introduction

1.1 Software Introduction

The total station transmission software was designed to bridge the Total station and PC to transmit data.

The Total station communicate with PC by a serial cable, before connection you should install the cable driver, otherwise, it can not communicate.

NOTE: Do not need to install the software, just double click it and run it.


2. Installation of Data Cable Driver

2.1 Installation Steps of Data Cable Driver


1. Run the driver software  CP210xVCPInstaller_x64.exe or  CP210xVCPInstaller_x86.exe . For this installation you need rights of administrators. For WIN7 operation system, select it and right click it, there will be a prompt *Run as administrator*.



2. Choose the setting as is shown, click *next*.



3. Click *next*.




4. Click “Finish”, and complete *installing*.

5. Plug in USB port to PC.



Total Station Transmission Software

6. It will prompt you it is installing, after the PC recognise driver, and tell you the current port is COM3.



3. Software Usage

3.1 Transmit Data from TS to PC

Transmitting data, transmit the measurement file to PC.


Operation Steps:

1. Install battery (at least half of the full electric quantity) , Plug in 6pin serial port to total station.




Total Station Transmission Software


2. Double click the software to run it



3. Choose the serial port COM3. (If you have already installed the USB driver, then you can check the serial port in Device Manager.



Total Station Transmission Software



4. Press power button, and run the machine.

1) Operation of Sending Measurement Data

Press “ESC” → “MEM” → “Working Job” → “Comms.

output” → “Select Disc”, and then you select a disc, then press

“Ok” → “NEXT”, then you will get this interface:

Total Station Transmission Software



Here, press “↑” “↓” to change baudrate, to match with the PC.


2) Operation of Sending Coordinate Data

Press “ESC” → “MEM” → “Know Data” → “Comms. send”, as follow:



Total Station Transmission Software


5. Click “Receive”, start to receive data from total station. (Watch the steps, click “Receive” first, then press “F4”)



6. Press “F4” on the total station operation panel, and start to transmit data, after the transmission finished, you can refer to “Number” on total station screen to get the data quantity , the number must be the same with “Total” on the software.


7. After finishing the transmission, the data quantity will be shown on the software status bar, the quantity should be the same with that in total station.

Total Station Transmission Software




8. After the transmission software got the data, you can save it.

Option 1: Press "Save".




Total Station Transmission Software

Click “Save” and you will get the dialogue box, name it and select a file format, as follows:




Option2: Press “Export” and save it.


Total Station Transmission Software



Go to data outputting interface, select the wanted coordinate format, and click “Export”, if you want, you can go to “Preview the data”.



Click “Export” and name it, select the file format, and save it.



9. If you marked the “Preview the data”, then you click “save”, the saved file will be automatically opened, convenient for you to preview.

Total Station Transmission Software

PC-IO DATA 1.1.7 (2013-07-09 EN)

NUM	PT#	N	E	Z	PCODE
1	S1	7.0000	4.0000	1.0000	
2	S2	8.0000	5.0000	2.0000	
3	1	6.2730	4.3880	13.1720	
4	2	6.2730	4.3880	13.1720	
5	3	-3.7000	11.1300	12.3420	
6	1	2344.2340	0.3400		
7	2	5422.2230	0.2200		
8	3	2444.2220	0.2330		
9	JOB	00000.J0	0.0000		
10	INST	HTS221	0.0000		
11	SC	1	0.0000		
12	NEZ	1.000	1.0000		
13	SC	2	0.0000		
14	NEZ	2.000	2.0000		
15	SC	3	0.0000		
16	NEZ	3.000	3.0000		

levi.coo - Notepad

```

File Edit Format View Help
S1, 7. 0000, 4. 0000, 1. 0000,
S2, 8. 0000, 5. 0000, 2. 0000,
1, 6. 2730, 4. 3880, 13. 1720,
2, 6. 2730, 4. 3880, 13. 1720,
3, -3. 7000, 11. 1300, 12. 3420,
1, 2344. 2340, 0. 3400, 3. 1000, 0
2, 5422. 2230, 0. 2200, 2. 3000, 0
3, 2444. 2220, 0. 2330, 1. 3000, 0
JOB, 00000, J0, 0. 0000, 0. 0000, 0. 0000
INST, HTS221, 0. 0000, 0. 0000, 0. 0000
SC, 1, 0. 0000, 1. 5000, 0. 0000
NEZ, 1. 000, 1. 0000, 1. 0000, 0. 0000
SC, 2, 0. 0000, 1. 5000, 0. 0000
NEZ, 2. 000, 2. 0000, 2. 0000, 0. 0000
SC, 3, 0. 0000, 1. 5000, 0. 0000
NEZ, 3. 000, 3. 0000, 3. 0000, 0. 0000
    
```

ComPort Setup
 ComPort: COM12
 BaudRate: 19200

File Transfer
 Coordinate File

Successfully exported! Rtc: 29 Receive data:Click "Receive" button within 20 seconds after the instrument click the "Export" button


3.2 Transmit Data from PC to Total Station

Procedure:

1. Connect the PC and TS by cable.
2. Turn on machine.

1) Transmit data to working Job:


Press “ESC” → “MEM” → “Working Job” → “Comms. Input” → “Select File Received”, and then you select a disc, then press “Ok” → “NEXT”, then you will get this interface:




2) Transmit Data to Known Data:

Press “ESC” → “MEM” → “Know Data” → “Comms. receive”, as follow:

Total Station Transmission Software




3. Run the transmission software, choose “coordinate file” in “File transfer”, and click “Input”, then you will go into coordinate inputting interface.




Total Station Transmission Software

4. Select the inputting coordinate format, then click “input”.




Select the “File format” and click “Open”.




Total Station Transmission Software

5. After inputting data, the data will be displayed, as is shown below, then click “Return”.



6. Click “Send” and start to send coordinate file.


Total Station Transmission Software



7. Press F4 “RECV” on total station, after it finished, the data number will be shown on TS screen, which is the same figure as that on transmission software status bar.

3.3 Copy Data and Paste Data

1. After you inputting or opening the coordinate file, click “copy data”.




2. Open EXCEL, paste the data to EXCEL table. The data sequences: point name, N, E, Z, code.

	A	B	C	D	E
43					
44	1001	20001	10001	0.001	c001
45	1002	20002	10002	0.002	c002
46	1003	20003	10003	0.003	c003
47	1004	20004	10004	0.004	c004
48	1005	20005	10005	0.005	c005
49	1006	20006	10006	0.006	c006
50	1007	20007	10007	0.007	c007
51	1008	20008	10008	0.008	c008
52	1009	20009	10009	0.009	c009
53	1010	20010	10010	0.01	c010
54	1011	20011	10011	0.011	c011
55	1012	20012	10012	0.012	c012
56	1013	20013	10013	0.013	c013
57	1014	20014	10014	0.014	c014
58	1015	20015	10015	0.015	c015
59	1016	20016	10016	0.016	c016
60	1017	20017	10017	0.017	c017
61	1018	20018	10018	0.018	c018
62	1019	20019	10019	0.019	c019
63	1020	20020	10020	0.02	c020
64	1021	20021	10021	0.021	c021
65	1022	20022	10022	0.022	c022
66	1023	20023	10023	0.023	c023
67	1024	20024	10024	0.024	c024
68	1025	20025	10025	0.025	c025

Total Station Transmission Software

3. On the contrary, you can also copy the data in the EXCEL to the transmission software. The data sequences: point name, N, E, Z, code.




3.4 Create Coordinate File

You can edit a coordinate file manually by transmission software


Here are the steps:

1. Run the transmission software, click “New” in file transfer, and select the coordinate file.




Total Station Transmission Software

2. In the coordinate editing interface, input point name, N, E, Z, code.





3. Click “Append” when you want to add the next data, you can edit the figure on the table directly.




Total Station Transmission Software

4. If you want to delete some data, click “Delete”, and confirm your operation--click “Yes” in the prompt.




Total Station Transmission Software

5. You can click “Search” to get quick access to the wanted point, input the point name in the blank and click search, then you will get it.



6. Finished editing, click “Return” and go back to the main interface, you can upload the data to PC or total station.




Notice: The operation of creating code file is the same with that of coordinate file, the code file name is PCODE.LIB.

4 Instruction of connecting controller with the instrument by Bluetooth

4.1 Set in total station

After pressing the start button, press the [CNFG] button to enter the config interface, and then press the number key 4 “Com. Para.” to select Bluetooth option.



Click the F4 key to confirm and click [ESC] key to cancel.

4.2 Set in the controller

1. Bluetooth Settings

1). Go to “Settings” and then “Bluetooth” to set the Bluetooth.

Total Station Transmission Software




2). Click “Add new device” to search the total station. Then you will see the it in the list. Then click “Next”, enter the pin code “1234” and then click “Next”.




3). Click “COM Ports” in the bottom, then click “New Outgoing Port” to select

a port.



4). Choose a unused port and then click “Finish”.




2 Bluetooth connections in SurvCE


- 1). Run SurvCE software.
- 2). Click “Equip” and then “1Total Station” in the main interface of SurvCE software..



- 3). In “Current” interface, select “Topcon Direct” for “Manufacturer” and “GTS Series (non-motorize)” for “Model”.



4). Then go to “Comms” interface, select “Bluetooth” for “Bluetooth” and “Generic” for “BT Type”. As to the com port, it’s the one you selected in the Bluetooth setting.




3 Store points

1). Click the “Store Points” items in the “Survey” options.



2). Select the upper-left corner of [R], you can remotely operate the instrument to measure, and display the data on the instrument on the blow screen.

Total Station Transmission Software



The data display on the hand book show that the instrument is connected to the hand book.